

NOKIA

Gizmo for S60
Get Started Guide



Contents:

INTRODUCTION TO GIZMO	4
GET STARTED	5
Go online using a new account	5
Go online using an existing account	7
Go online and offline	8
CONTACT LIST	9
Add a contact	9
Remove a contact	9
PRESENCE	10
Change your status information	10
INSTANT MESSAGING	11
Start an IM conversation	11
End an IM conversation	11
CALL	12
Make internet calls	12
Make Call Out calls	12
Make GSM calls	13

© 2007 Nokia. All rights reserved.

Nokia is a registered trademark of Nokia Corporation. Other product and company names mentioned herein may be trademarks or trade names of their respective owners.

Reproduction, transfer, distribution, or storage of part or all of the contents in this document in any form without the prior written permission of Nokia is prohibited.

Nokia operates a policy of ongoing development. Nokia reserves the right to make changes and improvements to any of the products described in this document without prior notice.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, UNDER NO CIRCUMSTANCES SHALL NOKIA OR ANY OF ITS LICENSORS BE RESPONSIBLE FOR ANY LOSS OF DATA OR INCOME OR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL OR INDIRECT DAMAGES HOWSOEVER CAUSED.

THE CONTENTS OF THIS DOCUMENT ARE PROVIDED "AS IS". EXCEPT AS REQUIRED BY APPLICABLE LAW, NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE MADE IN RELATION TO THE ACCURACY, RELIABILITY OR CONTENTS OF THIS DOCUMENT. NOKIA RESERVES THE RIGHT TO REVISE THIS DOCUMENT OR WITHDRAW IT AT ANY TIME WITHOUT PRIOR NOTICE.

The availability of particular products and applications and services for these products may vary by region. Please check with your Nokia dealer for details, and availability of language options.

Some operations and features are SIM card and/or network dependent, MMS dependent, or dependent on the compatibility of the devices and content formats supported. Some services are subject to a separate charge.

INTRODUCTION TO GIZMO

This guide tells you how to get started with Nokia Gizmo for S60 application in your compatible Nokia mobile device. Gizmo enables instant messaging (IM), internet calls, and presence, a feature indicating in real time which of your Gizmo contacts are online and possibly available for messaging.

For more detailed instructions on how to use Gizmo, see *Gizmo user guide*.

GET STARTED

To start using Gizmo, you must download and install the application to your compatible Nokia mobile device.

Tip! You can download the Gizmo application from the Download! catalogue of your compatible Nokia mobile device.

Downloading Gizmo application may involve the transmission of large amounts of data through your network service provider's network. For information about data transmission charges, contact your network service provider.

After installation, you can go online with Gizmo using either wireless LAN (WLAN) or GPRS. If your compatible Nokia mobile device supports WLAN usage and if you are in the range of a wireless network, using WLAN is recommended. Using GPRS can generate data transmission charges. For more information, contact your network service provider.

Some places, like France, have restrictions on the use of wireless LAN. Check with your local authorities for more information.

Important: Always enable one of the available encryption methods to increase the security of your wireless LAN connection. Using encryption reduces the risk of unauthorised access to your data.

Go online using a new account

To create a new account for going online, do the following:

1. In the standby mode in your compatible Nokia mobile device, select **Menu > Contacts**, and scroll to the Gizmo application tab.
2. Select **Options > Select > Create new account > OK**.
3. To connect to the server, select **Yes**. A browser window opens.
4. Enter the required information on the Gizmo webpage, read the user agreement, and if you agree to the terms of the user agreement, select the check box and **Sign up**.

GET STARTED

Take note of your user details displayed on the webpage after the account creation.

5. To download settings to your Gizmo application, follow the prompts in the webpage.
6. To continue account creation, some devices require you to select **Options > Open > Yes**.
7. Select if you want to allow GPRS usage. Allowing GPRS usage enables you to continue an IM conversation even if you move out of reach of a WLAN connection. If you allow GPRS, accept the disclaimer, and select the desired internet access point (IAP) on the list.
8. To go online in Gizmo, select the connection type (**Automatic WLAN, Manual WLAN** or **GPRS**).

With **Manual WLAN**, you select the access point to use.

Automatic WLAN automatically selects the optimal access point available of the ones you have used earlier in you device. If none are recognised, you select the access point to use.

9. If prompted, select the WLAN access point to use.
10. If you select **Hidden WLAN** as access point:
 - a. Enter the WLAN SSID, and select **OK**.
 - b. Select the security mode, and select **OK**.
 - c. Enter the network password, and select **OK**.

Go online using an existing account

To use an existing account for going online, do the following:

1. In the standby mode in your compatible Nokia mobile device, select **Menu > Contacts**, and scroll to the Gizmo application tab.
2. Select **Options > Select > Use existing account > OK**.
3. Enter your Gizmo user name and password in the relevant fields, and select **OK**.
4. Select if you want to allow GPRS usage. Allowing GPRS usage enables you to continue an IM conversation even if you move out of reach of a WLAN connection. If you allow GPRS, accept the disclaimer, and select the desired IAP on the list.

Some places, like France, have restrictions on the use of wireless LAN. Check with your local authorities for more information.

5. To go online in Gizmo, select the connection type (**Automatic WLAN, Manual WLAN** or **GPRS**).

With **Manual WLAN**, you select the access point to use.

Automatic WLAN automatically selects the optimal access point available of the ones you have used earlier in you device. If none are recognised, you select the access point to use.

Important: Always enable one of the available encryption methods to increase the security of your wireless LAN connection. Using encryption reduces the risk of unauthorised access to your data.

6. If prompted, select the WLAN access point to use.
7. If you select **Hidden WLAN** as access point:
 - a. Enter the WLAN SSID, and select **OK**.
 - b. Select the security mode, and select **OK**.
 - c. Enter the network password, and select **OK**.

GET STARTED

Go online and offline

To use Gizmo's communication features, you must go online in Gizmo. You can connect Gizmo to the internet by using either WLAN or GPRS. With WLAN, you can make the fullest use of Gizmo.

To go online in Gizmo, do the following:

1. In the standby mode in your compatible Nokia mobile device, select **Menu > Contacts**, and scroll to the Gizmo application tab.
2. Select **Options > Select**, and the connection type (**Automatic WLAN, Manual WLAN or GPRS**). If GPRS is not allowed in the settings, GPRS is not listed as an option.
3. If you select **Manual WLAN**, select the WLAN access point to use.
4. If you select **Hidden WLAN** as access point:
 - a. Enter the WLAN SSID, and select **OK**.
 - b. Select the security mode, and select **OK**.
 - c. Enter the network password, and select **OK**.

To go offline, in the main view, select **Options > Go Offline**.

CONTACT LIST

The contact list contains all your Gizmo contacts and shows their presence status. You can also view the details of your Gizmo contacts. To maintain your contact list, you can add new Gizmo contacts and remove existing ones.

Add a contact

1. In the main view, select **Options > Invite new contact**.
2. Select the contact type (**Gizmo**, **Google** or **Other**).
3. Enter the username of your Gizmo contact. If you select **Gizmo** or **Google** as the contact type, the domain name is filled in automatically.
4. Select **OK**.

The people you add to your Gizmo contact list receive a message inviting them to become your Gizmo contacts. When the other party accepts your invitation, your presence statuses are displayed to each other.

Remove a contact

1. In the main view, scroll to the Gizmo contact you want to remove from your list, and select **Options > Delete**.
2. To confirm the deletion, select **Yes**.

The Gizmo contact is removed from your contact list. Respectively, your name is no longer available on that person's Gizmo contact list.

PRESENCE

PRESENCE

The idea of presence is to inform others of your willingness and ability to communicate using the Gizmo application.

On your Gizmo contact list, each Gizmo contact's presence status is indicated with an icon. Your Gizmo contacts are listed according to presence statuses in the following order:

- Available
- On the Phone
- Away
- Do Not Disturb
- Invisible/Offline

An hourglass icon is displayed next to a newly-invited Gizmo contact who has not yet accepted your invitation.

Change your status information

1. In the main view, scroll to **My Status**, and select **Options > Open**; or scroll to any Gizmo contact, and select **Options > My status**.
2. Scroll to the desired presence status, and select **OK**.

Your status change is visible to your Gizmo contacts in real-time.

INSTANT MESSAGING

IM is an easy way of communicating with your Gizmo contacts by sending and receiving instant messages using the Gizmo application.

Using GPRS for sending instant messaging can generate data transmission charges. For more information, contact your network service provider.

Start an IM conversation

1. In the main view, scroll to the Gizmo contact to whom you want to send an IM, and select **Options > Send IM**.
2. Enter your message in the message field.
3. To send the IM, select **Options > Send**.

The reply IM from your Gizmo contact is displayed in blue colour.

If you want to return to the main view without ending the conversation, select **Back**.

To access an active IM conversation from the main view, scroll to **IM conversat.**, and select **Open**. If you have multiple active IM conversations, scroll to the desired IM conversation tab.

End an IM conversation

1. In the main view, scroll to **IM conversat.**, and select **Open**. If you have multiple active IM conversations, scroll to the desired IM conversation tab.
2. Select **Options > End conversation**.

CALL

CALL

Gizmo enables you to make internet, Gizmo Call Out, and GSM calls directly from your Gizmo contact list.

Depending on the capabilities of your device and your connection type, your device offers you the optimal available call type, prioritising internet calls whenever possible. In the Gizmo main view, an icon is also displayed next to **My status** if you are able to make internet and Call Out calls.

Your device supports voice calls over the internet (internet calls). Your device attempts emergency calls primarily over cellular networks. If an emergency call using cellular networks is not successful, your device attempts an emergency call through your net call provider. Due to the established nature of cellular telephony, you should use cellular networks for emergency calls, if possible. If you have cellular network coverage available, make sure that your cellular phone is switched on and ready to make calls before you attempt an emergency call. The capability for an emergency call using internet telephony depends on the availability of a WLAN network and your internet call provider's implementation of emergency call capabilities. Contact your internet call provider to check the internet telephony emergency call capability.

Make internet calls

To make an internet call, select **Options > Call** on the Gizmo contact list or in the IM conversation window during an active conversation. On the list of call types, select the internet call.

Make Call Out calls

If your Gizmo contacts have entered additional phone numbers to their Gizmo account details, you can make internet calls to their landline and

mobile numbers. Some phone numbers may require you to buy Call Out credits.

To make a Call Out call, select **Options > Call** on the Gizmo contact list or in the IM conversation window, and select the desired Call Out option.

Make GSM calls

If internet and Call Out calls are not available (there is no icon next to **My status**), your calls are routed over the cellular network.

If your Gizmo contacts have entered additional phone numbers to their Gizmo account details, you can make GSM calls to their landline and mobile numbers. Select **Options > Call** on the Gizmo contact list or in the IM conversation window, and select the desired GSM call option.